

Install 2" Plaster Ring Adapter (Remodel)

	CEILING	1: Cut away the drywall where the junction box is located.
#8-32		2: Remove the plaster ring by removing the #8-32 screws.
	STANDARD PLASTER PLATE #8-32 SCREW	 3: Install the 2" Plaster Ring to the junction box using two #8-32 screws. 4: Plaster and finish around the junction box opening. 5: Complete installation by following steps in "Install Fast Jack Port" section on Page 2.
(2)		

Install Fast Jack Port

