### $\underline{A}\underline{merican}\underline{B}\underline{rass}\, \mathcal{E}\underline{C}\underline{rystal}$ Casting a Finer Light

# American Brass & Crystal

Casting a Finer Light



# FM2065

American Brass and Crystal provides the finest quality components manufactured, designed and finished by master artisans. We take great pride in our production abilities and we empower our valued customers with the ability to custom create the light that is perfect for them.

Enclosed are detailed instructions on how to properly assemble and install your chandelier. If you have any questions please call our toll free customer service hotline at: 1-(877)-465-5617

American Brass and Crystal
835 Lehigh Avenue, Union, NJ 07083 www.abclighting.net




## Crystal Component Detail



Quantity: 1

(40mm Ball w/ 3-14mm-Oct)

Connect to bottom Center finial.



Letter: B Quantity: 5

(4h+2h+4h+2.5"w/ 5-14mm Drape -c.8) Connect to back hole of arms. (REFER TO DAIGRAM 1)



Letter: C Quantity: 5

(4h+2h+4h+2.5"w/ 12-14mm Drape -c.8)

Connect to front hole of arms. (REFER TO DAIGRAM 1)

Letter: D Quantity: 20

(2.5"U w/14mm Oct)

Connect to front 4 hole on each of the 5 bobeches. Make sure to leave back two holes open to accept drops from leter E)



(3h +12-14mm double drape + 3 hole + 2.5"U)

Connect top to crown cover and bottom to back two holes of bobeche beneath it.




(4h+1-14mm+2" Right: 2-14mm+3h+2-14mm +1-14mm +2.5"U) Connect to top crown holes.

(REFER TO DIAGRAM 1)


Note: Diagrams are just representative

### **Crystal Trimming Directions**

Begin trimming your chandelier after all of the electrical connections have been made, the lights have been tested and all is in good working order. Begin trimming in Alphabetical order. Do not unwrap the next letter until the previous one is complete.



#### (Diagram 1)



Connect draping crystal to open hole on 4 hole crystal of the same letter on the adjascent arm. For letters "B", "C" and "CR1"