

- 1. Carefully unpack and identify all parts referring to illustration for parts identification.
- 2. Turn the power to the installation point OFF.
- 3. While threading the wire through, assemble the rods (4) together using the nipples (3). Attach the bottom end of rods (4) into the socket assembly (6) until tight.
- 4. Secure the top of the rods (4) onto the loop (5).
- 5.Refer to the additional installation instructions included with the product for wiring and installation.
- 6.Use the link to connect the loop (5) to the loop on the canopy (1) and twist the locking mechanism to secure.
- 7.Install the glass shade (7) over the socket assembly (6) and secure with socket ring (8).
- 8.Install proper bulbs (not included) into each socket referring to the markings and/or labels on the fixture for maximum wattage.
- 9. Restore power to the installation point and retain this sheet for future reference.