



ASSEMBLY INSTRUCTION MODEL # SOT-18013-MK-GA





- 1. Decide the preferrred hanging height and choose the correct length of rod needed.
- 2. Feed the wire through the stems and connect the stems together.

How to Install

- Screw one end of the stem assembly onto the top of the frame. Slip the canopy over the stem assembly and screw the ball swivel onto it.
- 4. Install the mounting plate onto the outlet box.
- 5. Raise the fixture up onto the ceiling and do the wire connection. Secure the canopy with the canopy screw. Make sure the slots on the ball swivel align with the nipple on the canopy before tightening the canopy using a screw.
- 6. Install the bulb onto the socket.





PART NUMBER MODEL # SOT-18013-MK-GA



Part Number

- A. (1) Mounting Hardware
- B. (1) Ball Swivel
- C. (1) Canopy(W4.9", H0.9") #XRE18013MKGACAN4.9IN
- D. (1) Hanging Stem(6",12.70mm) #XRE18013MKGASTEM6IN
- E. (3) Hanging Stem(12",12.70mm) #XRE18013MKGASTEM12IN
- F. (4) Threaded Nipple
- G. (1) Scoll Arm Kit
- H. (4) Finial #XRE18013MKGAFIN
- I. (4) Screw
- J. (2) Canopy Screw