




SAVOY
HOUSE

ITEM NO: 7-4286-1



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Assemble the tube (C, D) together and thread the bottom end of the extension rods into coupling (E) until snug. Thread the top end of the extension rods onto canopy (A).
4. Place the canopy (A) over the crossbar, and allowing the mounting screws to go through canopy (A), then secure with round nuts (B).
5. Install the shade (F) onto the socket (E) and secure with the socket ring (G)
6. Install the bulb (not included) into the socket (E).
7. Refer to the additional installation instructions included with the product of wiring and installation.
8. Restore power to the installation point and retain this sheet for future reference.