



- Shut off the main electrical supply from the main fuse box/circuit breaker.
- Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.
- Please be sure you have all parts indicated before you beigin assembly.
- Gently pull wiring down from ceiling junction box and allow to hang.
- Remove the mounting plate(A) from the canopy(B) by unscrewing the collar loop(C).
- Connect lamp body (F) and canopy (B) with rod(DI,D2,D3,D4), loosen the small hex screws (E) first then tighten with allen wrench (V), after all rods are connected. Be sure all the hexangular screws are tight enough. Note: if you want the fixture to be semi-flush mount, you only need connect lamp body (F) and canopy (B) with rod (D4).
- Drill 1 hole inside the junction box and fasten the bracket (P) to ceiling by screwing the strengthen screws (O) into. Drilled hole as fig 1. "If attach to cement ceiling, use plastic anchor (R) first then screw strengthened screws (O) into the plastic anchor (R). "If attach to wood ceiling, thread strengthened screw (O) directly into ceiling, pass the steel wire (M) through the hole of bracket (P), and pass the steel wire (M) through the 2 holes of coupling (N), then fix with 2pcs screws provided in the coupling (N) at fig 2. Be sure to tighten two screws attached on the coupling (N).
- Attach the mounting plate (A) to the outlet box by using the mounting screws(J).
- Carefully inspect the pendant's fixture wires. Neutral fixture wire: white hot fixture wire: black ground wire: green
- Wrap ground wire of lamp body and ground wire of junction box together and fasten together with a plastic wire connector (K) and wrap the connection with electrical tape. If your outlet box does not have a ground wire, insert the green ground screw into the mounting plate (A) facing down, and wrap the fixture's bare ground wire around the ground screw.
- Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire connector(K) and wrap the connection with electrical tape.
- Attach the hot fixture wire from the pendant to the to the hot junction box wire (usually black). Fasten each together with a plastic wire connector (K) and wrap the connection with electrical tape. Be sure no wire strands are exposed Do not reverse the hot and neutral connections or safety will be compromised.
- Gently tuck the wire connections neatly into the ceiling
- Attach the mounting plate (A) with nipple to the ceiling outlet box using the enclosed mounting screws (J) and tighten screws with a screwdriver.
- Push collar loop upto canopy (B) and tighten onto nipple in mounting plate (A) by turning in a clockwise to secure canopy.
- Insert 8 type a 60w bulb (or CFL 13w or LED 10w, not included) into the socket (H). **Do not exceed specified**
- Attach the glass (Q,L,S,T,U) into the holes of the arm carefully. Note: Glass with chain in 5 dimension as labeled. Please start from interior to exterior. When glass assembly is completed, remove label from the glass.
- 18. Restore power to the junction box and test fixture.

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

ARTERIORS