



# ASSEMBLY INSTRUCTIONS FOR YOUR ALLOY TASK FLOOR LAMP

## IMPORTANT SAFETY INSTRUCTIONS:

- \*This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- \*Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- \*Switch power off and remove plug from the wall outlet before replacing the bulb.
- \*This lamp is UL rated for dry locations.

## ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp base on a level surface.
2. Remove flange (A) from socket (C).
3. Place shade (B) onto socket (C). Thread flange (A) back onto the socket (C) to secure the shade (B) to the fixture.
4. Insert one 60W MAX. Type A, medium base bulb into socket (C).
5. To adjust lamp into the desired position, loosen turnknob (H) and move arm (G) into desired position. Repeat step using turnknob (F) to adjust arm (E) and turnknob (D) to adjust shade (B).  
Note: Adjust the lamp into the desired position before turning it on. When making any adjustments to the position of the lamp, turn the lamp off and allow the shade to cool if necessary as the shade can get very hot.
6. Remove protective plastic from plug (I).
7. Insert plug (I) into wall outlet.
8. Control power to the fixture by using the switch located on socket (C).

