

# ASSEMBLY INSTRUCTIONS FOR YOUR ELLIOTT PENDANT

# **IMPORTAN T SAFETY INSTRUCTIONS:**

- \* These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- \* WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.
- \* If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.
- \* This fixture is U.L. rated for dry locations.

### **ASSEMBLY INSTRUCTIONS:**

# SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.

- 1. Remove all parts from the carton. Do not throw away any parts.
- 2. Remove finial (O), washer (N) and acrylic diffuser (M) from threaded pipe (L). Keep these parts for later use.
- 3. Install three 5W G9 Bi-Pin LED bulbs (K) into the sockets.
- 4. Slide acrylic diffuser (M) and washer (N) up threaded pipe (L) and hold firmly against the washer at the end of threaded tube (L). Thread finial (O) onto threaded tube (L) to secure parts (M) and (N) to the fixture.
- 5. Remove canpoy (D) and threaded collar (F) from hang straight (E) and set aside to be used later. Affix crossbar (B) to outlet box using screws (C) provided. Keep hang straight (E) attached to threaded pipe (A).
- 6. Measure desired drop for fixture to hang and add/remove extension tubes (I). Guide wiring through extension tubes before threading tubes together.

  \*\*ADD/REMOVE EXTENSIONS: (Un)Thread the threaded nipple of one extension into the threaded opening of the next extension. Make sure wiring is pulled tight when threading extensions together to prevent damage to the wire\*\*. Thread bottom of extension rod (I) to the exposed threading on the top of shade (J) to secure extension rods (I) to the fixture.
- 7. Slide threaded collar (F) down extension rods (I) and let rest on shade (J). Slide canopy (D) down extenion rods (I) and let rest on threaded collar (F).
- 8. With quick link (G) in the open position, slide quick link (G) onto loop (H) and lift fixture onto hang straight (E). Close hang straight (G).
- 9. Guide wiring through threaded tube (A) and follow instruction to make the proper electrical connection. Note: At least 8 inches of wire is needed to make proper electrical connections.

#### A LICENSED ELECTRICIAN IS RECOMMENDED.

- 10. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
- 11. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
- 12. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
- 13. Carefully push wire connections back into the ceiling outlet box. Slide canopy (D) up extension rods (I) and hold firmly against ceiling. Slide threaded collar (F) up extension rods (I) and thread onto hang straight (E), securing canopy (D) against ceiling.
- 14. Reconnect main electrical supply from the fuse box/ circuit breaker and test the fixture.

