



# ASSEMBLY INSTRUCTIONS FOR YOUR KANE GLASS SHADE PENDANT

## IMPORTANT SAFETY INSTRUCTIONS:

- \* These instructions are provided for your safety. It's important that all safety instructions are read before beginning installation of fixture.
- \* We **STRONGLY** recommend installation by a licensed electrician.
- \* Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- \* Do not connect the electricity until lamp is fully assembled.
- \* This fixture is UL rated for damp locations.

## ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts from carton. Do not throw away any parts.
3. Unthread glass shade (K) from housing (I) and set aside on a soft surface.
4. Remove mounting plate (B) from canopy (D). Do this by unthreading screws (E) from mounting plate (B).
5. Carefully pull the wiring from the ceiling outlet box. Guide the wires through the center hole in mounting plate (B).
6. Affix mounting plate (B) to outlet box with mounting screws (C) provided.
7. Determine the desired height for the fixture to hang and adjust the cord length accordingly. To add or remove length from the cord, carefully loosen screw (G) from clamp (F) with small flat head screwdriver (not included). Pull cord up or down through canopy (D) to achieve desired length. To secure cord in place, carefully tighten screw (G) with screwdriver until hand tight. Note: Do not over tighten as this may cause damage to plastic clamp (F).
8. If necessary, cut extra cord above canopy (D). NOTE: leave at least six inches of cord above canopy (D) in order to make proper wire connections.
9. Lift the canopy to the ceiling and make the proper electrical connections noted in steps 10 through 12. A LICENSED ELECTRICIAN IS RECOMMENDED.
10. Attach ground wire from fixture (green or copper in color) to ground wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
11. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
12. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
13. Gently push the wire connections back into the ceiling outlet box.
14. Place canopy (D) over mounting plate (B), aligning holes in canopy (D) with the threaded holes in mounting plate (B).
15. Secure canopy (D) to mounting plate (B) by threading screws (E) into mounting plate (B).
16. Install one 120 volt 4W MAX, G9 Bi-Pin LED, G9 base bulb (included) into socket (J).
17. Slide shade (K) over socket (J). Thread shade (K) back into house (I) to secure shade (K) to fixture.
18. Reconnect the main electrical supply at the fuse box/ circuit breaker and test the fixture.

