

Austin

Assembly Instructions



THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED








VIRO-0001



Scan to view online

VIRO-0001

Part Names and Quantities

	<p>VIRO-PEN-0001</p> <p>1 Socket + Cord</p>
	<p>VIRO-CAN-0001</p> <p>1 Single Canopy</p>
	<p>1 Universal Mount</p>
	<p>2 8-32 Junction Box Screws</p>
	<p>2 Canopy Mount Threaded Rods</p>
	<p>2 Locking Nuts</p>
	<p>2 Wire Nuts</p>

READ FIRST

BEFORE CUTTING THE CORD

To cut the cord, follow these steps to prevent the cord's cloth cover from fraying and to ensure successful assembly and installation.

1. Determine the position the cord hangs from the canopy. The cut position is 3 inches above that.



2. Wrap electrical tape around the cut position.




3. Cut the cord in the middle of the electrical tape and continue to assemble and install the fixture as shown in the instructions.



4. After the fixture is assembled and during canopy installation, remove the tape, strip the cord and wires, then connect them to your junction box's wires as shown in the instructions.


1. Install the universal mount

Screw the Universal Mount onto the ceiling junction box




2. Install the canopy mounting rods

Screw the threaded rods into the universal mount




3. Install the cord into the canopy

Cut the cord to length, insert it into the canopy and lock it




4. Connect the electric and ground wires

Connect ground wires to ground terminal and then match power with power and neutral with neutral wires



5. Install the canopy

Align the canopy to the mounting rods and install



6. Lock the canopy in place

Screw the locking nuts onto the canopy mounting rods

