

REGINA ANDREW

DETROIT

ITEM NO: 14-1060 Spyder Floor Lamp

PLEASE NOTE THAT IF ADJUSTABLE CLUTCH IS NOT LOOSENED BEFORE ADJUSTING THE HEIGHT, PERMANENT DAMAGE TO THE MECHANISM MAY OCCUR.

ASSEMBLY INSTRUCTIONS

1. Carefully remove all parts from box and remove all plastic covering from lamp parts.
2. Attach Pipe to Base Pipe with Alignment Pins pointing at the two holes on top of Base Pipe, with the shade pointing at the Horizontal Pipe of base. Meanwhile, pull out the cord from the Base pipe.
3. Remove the End Cap and tighten the two Long Screws from bottom of base pipe with the Allen Key provided. Then screw the End Cap back.
4. Insert the proper bulb into the socket. **NOTED: LED BULBS ARE RECOMMENDED.**
5. Insert the polarized plug into wall outlet, turn on switch and enjoy your new lamp.

CLEANING AND CARE:

Use a soft cloth only, do not use any chemical or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one-way. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Made in China

