



ASSEMBLY INSTRUCTIONS FOR YOUR WILLIAM LINEAR SCONCE

IMPORTANT SAFETY INSTRUCTIONS:

- *These instructions are provided for your safety. It's important that all safety instructions are read before beginning installation of fixture.
- *We **STRONGLY** recommend installation by a licensed electrician.
- *Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- *Do not connect the electricity until lamp is fully assembled.
- *This fixture is UL rated for Damp Conditions.

VERTICAL MOUNTING DIRECT WIRE ASSEMBLY INSTRUCTIONS:

DIRECT WIRE ASSEMBLY INSTRUCTIONS:

1. SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER. IT IS RECOMMENDED THAT A LICENSED ELECTRICIAN INSTALL THIS FIXTURE.
2. Remove mounting plate (B) from backplate (C) by removing screws (D). Lay screws (D) to the side.
3. Carefully pull the wiring from wall outlet box. Guide wires through the center hole in mounting plate (B). If optional cover plate (A) is required, guiding wires through cover plate (A) first, then through the center hole in mounting plate (B). Align mounting pattern in cover plate (A) and mounting plate (B).
4. Affix mounting plate (B) (and optional cover plate (A) to wall outlet box with mounting screws (E) provided. Use extra mounting holes in the top/bottom of cover plate (A) and mounting plate (B) for extra support.
5. Lift fixture (C) to mounting plate (B) and make proper electrical connections described in steps 6-8.
A LICENSED ELECTRICIAN IS RECOMMENDED.
6. Connect ground (green or silver in color) wire from fixture to ground wire in the outlet box. Fasten wires together with wire nut (F) and tightly wrap the connection with electrical tape.
7. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (F) and tightly wrap connection with electrical tape.
8. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (F) and tightly wrap connection with electrical tape.
9. Carefully push wire connections back into wall outlet box. Slide backplate (C) over mounting plate (B).
10. Thread screws (D) into holes at the top and bottom of backplate (C) to secure the fixture to mounting plate (B).
11. SHADE OPTIONAL; Carefully slide candle follower sleeve (located inside shade G) down candle (H) to secure shade to fixture.
12. Insert one 13W Max LED (60W Max incandescent) candelabra base bulb into socket.
13. Reconnect main electrical supply at the fuse box/circuit breaker and test the fixture.

