1718 W. Fullerton Chicago, IL 60614 Ph: 773.770.1195 • Fax: 773.935.5613 www.PureEdgeLighting.com • info@PureEdgeLighting.com © 2016 PureEdge Lighting. All Rights Reserved.

#### Installation Instructions for TruLine 1A L-Picture Frame Power Channel Connector

#### IMPORTANT INFORMATION


- This instruction must be used concurrently with other TruLine 1A BIY installation instructions.
- This product is wall or ceiling mount.
- This instruction shows a typical installation.


#### SAVE THESE INSTRUCTIONS!


# TL1A-LP\_-\_





# Section One: Install the Junction Box















#### Section Two: Prepare and Install the L-Picture Frame Power Connector






### Section Three: Install the LED Soft Strip - Single Feed (side mount)






- **5:** Place the power connection into the channel where the LED soft strip will be installed.
- **6:** Replace the trap doors and secure with the #4-40 screws using a 1/16" Allen wrench.


- 7a: Carefully remove the backing from the LED Soft Strip, making sure not to remove the tape. Line up the red wire side of the power connector with the "+24VDC" marking on the LED Soft Strip. Push the male connector of the LED Soft Strip into the L-Shaped Flexible Power Connector.
- **7b:** For RGBW Configurations, align the RGBW markings on the LED Soft Strip with the corresponding wires of the power connector. Push the male connector of the LED Soft Strip into the Flexible Power Connector.
- 8: Firmly press down the adhesive portion of the LED Soft Strip onto the side mount channel surface while removing the rest of the backing, making sure there are no air bubbles that can cause surface irregularities.






**9:** Trim excess LED Soft Strip ONLY at dashed cutting lines. Overlap excess LED Soft Strip at power connection to avoid dark spots in installation.

# Section Four: Install the LED Soft Strip - Dual Feed (side mount)




1: Refer to steps 1 through 4 in Section Three to uncoil the LED Soft Strip and connect each power connector to the Blank Power Tape (not used with RGBW), Power Adapter and L-Shaped Flexible Connector.




- **3a:** Carefully remove the backing from the LED Soft Strip, making sure not to remove the tape from the LED Soft Strip. Line up the red wire side of the power connector with the "+24VDC" marking on each LED Soft Strip. Push the male connector of the LED Soft Strip into the L-Shaped Flexible Power Connector.
- **3b:** For RGBW Configurations, align the RGBW markings on the LED Soft Strip with the corresponding wires of the power connector. Push the male connector of the LED Soft Strip into the power connector.
- **4:** Firmly press down the adhesive portion of the LED Soft Strip onto the channel surface while removing the rest of the backing, making sure there are no air bubbles that can cause surface irregularities.


# Section Five: Install the LED Soft Strip (bottom mount)




**NOTE:** This section is for installations where the LED strip will lay in the bottom of the channel.

**1:** Use pliers to bend the section of the short trap door cover  $\sim 90^{\circ}$  to allow for access to power connections.





## Section Six: Alternate LED Soft Strip Installation (bottom mount)



#### **Section Seven: Lenses**

<ol> <li>Use the whole lenses to cover L-Picture Frame Connector along with the rest of the installed channels.</li> </ol>