

1718 W. Fullerton Chicago, IL 60614 Ph: 773.770.1195 • Fax: 773.935.5613 www.PureEdgeLighting.com • info@PureEdgeLighting.com © 2016 PureEdge Lighting. All Rights Reserved.

Installation Instructions for **T-Bar Ceiling FreeForm Matte White** & Deep Cell Lens, 24VDC - Remote Power




IMPORTANT INFORMATION


- This instruction shows a typical installation.
- This product mounts on T-Bar grid ceilings.
- It is recommended more than one person to assist in this installation.

SAVE THESE INSTRUCTIONS!


Section One: Install the Fixture

| Α | 48" (121.9cm) | T-BAR CEILING | 1: Lay out all channels on the floor as a guide to determine where the system will be located on the T-Bar Ceiling. |
|-----------------------------|------------------|------------------|---|
| 48" (121.9cm) GENERAL | CHANNEL 48" | 48" (121.9cm) | |
| CONFIGURATION SHOWN | (121.9cm) | | |





- **6:** Continue to install additional channels one at a time until the system is complete.
- **7:** Lift the ceiling tile and route the power cable from each fixture to the remote power supply(ies). If necessary, drill out the edge of the tile slightly. Refer to the instructions provided with the power supplies.
- 8: Replace the ceiling tile.



General Wiring Diagram

