

Lamping Specifications Incandescent

- C10028 Belmont Sconce Candelabra Base One, B-10, 60W Max
- C10029 Belmont Sconce ADA Candelabra Base One, B-10, 40W Max

IMPORTANT | CAUTION

Read all instructions thoroughly, and turn off power at circuit breaker or fuse box before proceeding.

IMPORTANT! AT ALL TIMES WIRING TO BE DONE PER NATIONAL ELECTRIC CODES (NEC) OR APPLICABLE LOCAL CODES.

INSTALLATION

Step 1 Carefully unpack the fixture and shade and remove the mounting bracket from the backplate of the fixture.

C10028

C10029 ADA

Step 2 Orient the mounting bracket so that the holes line up with the holes in the junction box. Attach the mounting bracket to the outlet box. Be sure that the bracket is aligned on the wall so that once the fixture is installed it will be oriented vertically on the wall.

Step 3 With power off at the circuit/breaker make wire connections: connect black fixture wire to black supply wire (load typical); white fixture wire to white supply wire (neutral); attach fixture ground wire to ground wire or ground screw. Use wire connectors provided and push connections inside outlet box.

Step 4 Align the backplate of the fixture with the mounting plate on the wall. Push the backplate towards the wall over the mounting bracket and lower into position making sure that the tab on the rear of the backplate catches onto the flange of the mounting bracket. Note: the fixture will hang on the mounting bracket when installed properly.

Step 5 With backplate flush to the wall, secure into position by tightening the set screw with a hex key wrench. Do not overtighten.

Shade Installation

Clip on shade option, install candelabra lamp first then clip the shade onto the lamp.

Mounted shade option, install shade over the lamp holder and secure into place with shade ring. Install candelabra lamp.

Step 6 Install lamps per label recommendations. Restore power to circuit and illuminate lamp.

