

INSTALLATION:

- 1. Attach flared mounting bracket to outlet box as shown. Note: Universal mounting bracket is not required for some styles of outlet boxes and plaster rings.
- 2. Make connections using twist on connectors: connect black fixture wire to black supply wire; white fixture wire to white supply wire; fixture ground wire to box ground wire or terminal. Push all connections inside outlet box.
- 3. Position backplate of fixture over flared mounting bracket so that it is flush against wall. Secure by tightening top, then bottom set screws with hex key provided. Do not overtighten.
- 4. Install shade as illustrated on Page 2.

BOYD LIGHTING COMPANY 944 Folsom Street San Francisco, CA 94107-1007 Tel: 415.778.4300 Fax: 415.778.4319