



## INSTALLATION INSTRUCTIONS

C-10780 Nebula Pendant Small  
C-10781 Nebula Pendant Large

### IMPORTANT!

AT ALL TIMES WIRING TO BE DONE PER NATIONAL ELECTRICAL CODES (NEC) OR APPLICABLE LOCAL CODES. READ ALL INSTRUCTIONS THOROUGHLY. TURN OFF POWER AT CIRCUIT BREAKER OR FUSE BOX BEFORE PROCEEDING.

#### STEP 1

- Carefully remove fixture components from packaging. Avoid using a sharp blade on the packaging, as doing so may result in damage to the fixture or finish. Shade is alabaster. Handle with care.

#### STEP 2

- Separate canopy from end of cloth-covered cord.
- Unthread tapered collar on underside of canopy. Slide collar and canopy down cord (Figure 1).



Figure 1



Figure 2

#### STEP 3

- Loosen brass thumb knobs from support bracket. (Figure 2)
- Remove fixture assembly from mounting disk. Carefully set fixture aside for now.

#### STEP 4

- Secure mounting disk to electrical box with the provided screws (Figure 3)
- *Note: driver wiring shown removed for illustration purposes.*



Figure 3



Figure 4

#### STEP 5

- Make wire connections using included orange twist-on connectors. (Figure 4)
- **If installing on ELV/reverse-phase or MLV/forward-phase dimmers systems, or a basic switch:**
  - Connect the white driver lead to the neutral supply wire (typically white).
  - Connect the black driver lead to the hot supply wire (typically black).
  - Connect the copper fixture wire to the ground wire or ground terminal in the outlet box.
- **If installing on a 0-10V dimming system,,** follow the previous steps plus:
  - Connect the purple driver wire to the purple supply wire.
  - Connect the gray driver wire to the gray supply wire.
- **If 0-10V dimming is not required:**
  - Cap purple and gray wires as these wires are not needed.
  - Leave black and red driver wires dangling for hookup on a later step.

#### STEP 6

- Lift fixture up to mounting disk. Align support bracket over studs on disk (Figure 5)
- Secure with brass thumb knobs.

#### STEP 7

- Using provided lever-style connectors, connect fixture wiring to the driver (Figure 5)
- Pair the red (+) fixture lead to the red (+) driver wire.
- Pair the black (-) fixture lead to the black (-) driver wire.



Figure 5



Figure 6

STEP 8

- Tuck wire connections into canopy.
- Slide canopy up stem and secure in place with tapered collar (Figure 6)

STEP 9

- If alabaster shade needs to be removed or installed, slide brass cone up cord (Figure 7).
- Using a hex key, remove or install set screws. Alabaster cone is fragile so should be properly supported during this step.



Figure 7

STEP 10

- Restore power to fixture.