

SLCAN/ INTSTUD INSTALL INSTRUCTIONS

Attach SLCAN/ INTSTUD to wall stud using appropriate fixing screws.
Use hole saw to cut a clean hole 76mm/ 3" hole in wall cladding.
Attach wall cladding insuring cut hole aligns with SLCAN/ INTSTUD.
Insure minimum gap between SLCAN face and wall cladding once installed (3mm or 1/8" maximum)

WARNING: Do not fit LED lamp with higher then 6Watt rating when installed next to combustible material and / or insulation.

