

1105

A. Pour Concrete 13 ½"-15"

B. Bolts should be 4 ½"
into the concrete till
touching the triangle



