

1718 W. Fullerton Ave Chicago, IL 60614 Tel: 773-770-1195 Fax: 773-935-5613 www.edgelighting.com info@edgelighting.com


TAOS-W-SQ-LED-_

Installation Instructions for **Taos Square**


IMPORTANT INFORMATION


- This product is for indoor and outdoor locations.
- **<u>RISK OF FIRE</u>**: This product must be installed 4 ft above the ground for wet locations.
- This product is for wall mount applications only.
- This product can mount to either a 4" square electrical box with round plaster ring or an octagon electrical box.
- This product is not dimmable.

SAVE THESE INSTRUCTIONS!




Install the Fixture






7: Loosen the two M4 set screws on the fixture body (**Do Not Remove**) with the provided 2mm Allen wrench and carefully pull the canopy off of the fixture body.



- 8: Feed the LED brown and red driver wires through the canopy center hole, washer, and nut provided.
- **9:** Slide the canopy back onto the crossbar assembly nipple (make sure the gasket is in place) and secure the canopy to the crossbar assembly by tightening the nut.



NOTE: The fixture contains two 3 watt integrated LED lamps. These lamps are rated for 40,000 hours.

M4 SET SCREW