

Ы

the provided #8-32 screws.

crossbar assembly center hole.

5: Feed the brown and red LED driver wires through the

Installation Instructions for Taos Round

1718 W. Fullerton Ave Chicago, IL 60614 Tel: 773-770-1195 Fax: 773-935-5613 www.edgelighting.com info@edgelighting.com

## TAOS-W-RD-LED-

904-TAOS-W-RD-LED-06



## IMPORTANT INFORMATION - This product is ETL listed for indoor and outdoor locations. - **RISK OF FIRE:** This product must be installed 4 ft above the ground for wet locations. - This product is for wall mount applications only. - This product can mount to either a 4" square electrical box with round plaster ring or an octagon electrical box. - This product is not dimmable. - This product must be installed by a qualified electrician. SAVE THESE INSTRUCTIONS! **Install the Fixture** ELECTRICAL BOX Α **NOTE:** Turn off power to the junction box before installation. 1: Connect the white (NEUTRAL) LED driver wire to the neutral (2) power wire with a wire nut. LED DRIVER 00 2: Connect the black (HOT) LED driver wire to the hot power wire with a wire nut.

WIRE NUT

**3:** Place the LED driver and wire nut connections inside the electrical box.





