

1718 W. Fullerton Ave Chicago, IL 60614 Tel: 773-770-1195 Fax: 773-935-5613 www.edgelighting.com info@edgelighting.com NIGHT3-\_

904-NIGHT3-02



## Installation Instructions for Night Owl 3


## IMPORTANT INFORMATION

- This product is ETL listed for indoor locations.
- This product is for wall mount application.
- This instruction shows a typical installation for indoor.


## **SAVE THESE INSTRUCTIONS!**




## **Install the Fixture**




- **1:** Connect the LED driver white primary wire to the neutral power wire with a wire nut.
- **2:** Connect the LED driver black primary wire to the hot power wire with a wire nut.
- 3: Place the LED driver and wires inside the electrical box.



- **4:** Loosen **(Do Not Remove)** the two M3 set screws on top and bottom of the canopy with the 1.5mm Allen wrench provided.
- 5: Remove the crossbar from the canopy.



**6:** Line up the crossbar slots with the electrical box holes, and secure it in place by tightening the two #8-32 screws provided. Make sure that the crossbar is leveled horizontally.



- 7: Place the canopy onto the crossbar and secure it in place by tightening the two M3 set screws with the 1.5mm Allen wrench.
- **8:** Use the rocker switch to control the intensity of the light.

**9:** Rotate the front ring on the fixture head to adjust the beam spread to either a spot or flood.

**NOTE:** Rotate the front ring on the fixture head clockwise for a flood beam or counterclockwise for a spot beam.

**NOTE:** The fixture contains a **3 Watt** integrated LED lamp. This lamp is rated for 50,000 hours.

