

100 Craftway, P.O. Box 128 Littlestown, Pennsylvania 17340-0128

## INSTALLATION INSTRUCTIONS: AL43 PATHLYTE

The following lamps may be used in these fixtures: 20W T3 Halogen bi-pin (included) 10W T3 Halogen bi-pin	AL43	ROOF CAGE 
specifications. Failure to adh to the ballast and void the we equipment, nor to provide for	ere to these codes and instr arranty. These instructions d r every possible contingency	th the National Electrical Code and local code ructions may result in serious injury and/or damage o not purport to cover all details or variations in y related to installation, operation, maintenance, at are not addressed by these instructions, contact tain these instructions for future reference.
Lighted lamp is HOT! WARNING-	To reduce the risk of FIRE	O PERSONS-IMPORTANT SAFETY INSTRUCTIONS OR INJURY TO PERSONS: Turn off/unplug and ckly! Contact only switch/plug when turning on.

Lighted lamp is HOT! WARNING- To reduce the risk of FIRE OR INJURY TO PERSONS: Turn off/unplug and allow to cool before replacing lamp. Lamp gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure (see diagram/picture). Keep lamp away from materials that may burn. Do not touch the lamp at any time. Use a soft cloth. Oil from skin may damage lamp. Do not operate the luminaire fitting with a missing or damaged shield. SAVE THESE INSTRUCTIONS. Xenon lamps do not require additional shielding.

32001423, revision C

page 1 of 2



## INSTALLATION INSTRUCTIONS

- 1. Make sure power is turned OFF before installing or servicing the fixture.
- 2. This fixture must be mounted to a junction box or mounting stake that is UL listed for low voltage and wet locations. Mounting stakes \$1, \$6, \$7, \$8, and T\$375-12 may be used.
- 3. Route the wires from the fixture through the stem (order seperately) and thread stem into fixture.
- 4. Insert fixture wire through 1/2" NPS hole in stake cap and screw fixture into cap.
- 5. Wire fixture to supply cable with low voltage connector (included) by following the instructions below.
- 6. Attach stake cap to stake, being careful not to pinch wire.
  7. Remove the (2) screws that hold the roof to the cage and access the socket. Install T3 bi-pin lamp (20W max, 20W lamp included) and reassemble fixture.
- 8. Turn power ON.

## LOW VOLTAGE CABLE CONNECTOR INSTRUCTIONS

Low voltage cable connector to be used with 10 or 12 gauge supply cable and 18 gauge fixture cable. Philips recommends using SPT-3 water resistant (marked "WA", "W" or similar marking) supply cable such as our SCW500-10/BSCW500-10 or our SCW100-12/BSCW100-12. Philips also recommends ordering the entire system, which includes the power console (maximum 25 Amps, 15 Volts per circuit), fixture(s) (low voltage cable connector included) and supply cable to ensure proper installation and operation.

When using our supply cable, it can be laid on top of the ground, placed under "ground cover" (that is, shallow burial less than 6 inches or 15.2 cm deep), or directly buried in accordance with the NEC. If not using our cable, per UL 1838-Standard for Low Voltage Landscape Lighting Systems, the secondary cable must be SPT-3 or suitable for wet locations, sunlight resistant and direct burial per UL 493 and sized per UL 1838, and it must be buried less than 6 inches (15.2 cm). Philips recommends a minimum depth of 4 inches when burying in the lawn to prevent damage from aerators or other lawn plugging equipment. The 18 gauge fixture cable (provided with fixture) must be protected by routing in close proximity to the fixture or secured

to a building structure such as a house or deck. The fixture cable must be cut off so that it is connected to the low voltage cable connector within 6 inches (15.2 cm) of the fixture or the building structure. When making an underground connection to the 10 or 12 gauge supply cable (not provided), the fixture cable must not be buried more than 6 inches (15.2 cm). WARNING-Mount the luminaire in or on non-combustible mounting surfaces only.

- WARNING-Risk of Electric Shock. Install all luminaires 10 feet (3.05m) or more from a pool, spa, or fountain.
- Connect the supply cable to the terminals on the power console (transformer) and turn ON.
   Disassemble the connector by removing the Phillips head screw.
- 3. Inspect the connector to ensure the prongs are straight. If the prongs are bent, straighten with pliers.
- 4. Insert the end of the fixture cable into the square opening in the connector body. Bend wire over so that wire is laying in the recess marked '18 GA'. This will help hold the wire in place while performing steps 5 and 6. Only 2-wire cable is to be used and the common (smooth) wire and hot (ribbed) wires must be oriented as shown. 5. Press the supply cable into the recess marked '10,12/2 GA' on the connector body. Again the common (smooth) wires
- and the hot (ribbed) wires must be oriented as shown. 6. Press the connector cover onto the connector body, making sure the screw holes line up with each other.
- 7. Assemble the connector by tightening the Phillips head screw. NOTE: Make sure the metal prongs in the connector pierce all 4 wires; the fixture will light as the prongs pierce the wires.

