


CRYSTORAMA




Crystorama.com

LIGHTING THE WAY FOR SIXTY YEARS

ASSEMBLY INSTRUCTION MODEL #ACK-928-AG



All electrical components must be installed by a licensed electrician in accordance with the National Electric Code and the appropriate local electrical codes



You will need 8-Candelabra Base Bulb
40 Watts recommended 60 Watts Max.


USE LED BULBS FOR EXTENDED USE

The fixture is Damp rated

HOW TO INSTALL:

Place the fixture parts on a soft cloth-covered platform before installation of fixture.

1. Attach one end of the threaded pipe onto the ceiling joist and secure with the hex nut. The other end of the threaded pipe should protrude through the outlet box. Refer to page three for safety cable and additional mounting installation. Then move on to step 2.
2. Take one big check ring with the flat side up and place it over the hex nut at the top of the fixture frame. Then take the second big check ring, with the flat side down and place it on top of the first check ring. Feed the wire through both big check rings, the coupler, threaded pipe, and decorative rod in that order.
3. Secure the big check rings down with the coupler. Then screw the threaded pipe into the coupler.
4. Slide the decorative rod over the threaded pipe and secure all with the hex nut. Finish by placing the third big check ring, flat side up over the nut.
5. Decide the desired hanging height and choose the correct length of rod and chain needed.
6. Feed the wire through the rod (the long or short) and screw the rod onto the top of the decorative rod and secure it with the loop.
7. Raise the fixture up and make the wire connection. Attach the canopy to the mounting nipple, and secure it with the collar loop and collar ring.
8. Screw the short threaded pipe into the bottom of the fixture body. Slide the short tube and bottom spoke over it and secure with the hex nut. Place the small check ring over the hex nut and secure it with the finial.
9. Starting from the bottom, hang the glass onto the fixture frame.



Crystal Sets

- A. 15 Sets (1)8" Glass
- B. 22 Sets (1)14.5" Glass
- C. 15 Sets (1)11" Glass


WARNING: This product can expose you to Lead, which is known to the State of California to cause cancer and/or birth defects or reproductive harm. For more information go to www.p65warnings.ca.gov

CRYSTORAMA



LIGHTING THE WAY FOR SIXTY YEARS

ASSEMBLY INSTRUCTION MODEL #ACK-928-AG



Part Number

Part Numbers

- A.(1)-Mounting hardware
Washer x4.
Mounting Nipple x2.
Hex Nut x5.
Hickey x1.
Safety Cable x1.
Clamp x1.
Set Screw x2.
Wire Connector x2.
- B.(1)-Canopy(W5 1/8" x H3/4")
-XSN928AGCAN5IN
- C.(1)-Collar Ring
- D.(1)-Collar Loop
- E.(2)-Quick link
- F.(1)-Chain(5mm×72")
-XSN928AGCHA5MM
- G.(1)-Loop
- H.(3)-Big check ring ; Ø7/8"
- I.(1)-Long threaded pipe ; H6 1/8"
- J.(1)-Decorative rod ; H6"
-XSN921AGDECOROD6IN
- K.(1)-Coupler ; H1"
- L.(1)-Long rod ; H12"-XSN921AGROD12IN
- M.(1)-Short rod ; H6"-XSN921AGROD6IN
- N.(1)-Fixture body kit
Ø16"Spoke ring
Big check ring ; Ø7/8" x4.
Long tube ; Ø7/8",H4 1/8"
Ø24"Spoke ring
Short tube ; Ø7/8",H3 3/8"
Distributor box ; Ø3 1/8"
Socket x8.
Small check ring ; Ø3/4" x1.
- O.(1)-Short threaded pipe ; H4 1/4"
- P.(1)-Short tube ; Ø3/4", H3 3/8"
- Q.(2)-Small check ring ; Ø3/4"
- R.(1)-Spoke ring ; Ø16"
- S.(1)-Hex nut
- T.(1)-Finial

CRYSTORAMA


LIGHTING THE WAY FOR SIXTY YEARS



Crystorama.com

ASSEMBLY INSTRUCTION MODEL #ACK-928-AG

SAFETY CABLE INSTALLATION INSTRUCTIONS



IMPORTANT:

FOR A SAFE AND SECURE INSTALLATION, THESE FIXTURES MUST BE INSTALLED BY MEANS OF SUPPORTS THAT ARE INDEPENDENT OF THE OUTLET BOX.

SUGGESTED INSTALLATION:

1. Provide a 1/4 IPS pipe with one end securely mounted to a beam or a structural member. The other end should protrude through the center of the outlet, as shown.
2. Assemble the screw collar loop, nipple, hex nuts and hickey to center 1/4 IPS support pipe and adjust overall length to allow the collar ring to hold the canopy flush to the ceiling. When the adjustments have been completed secure the hex nut, as shown.
3. Use one quick link to connect fixture loop and the bottom of chain. Slide the screw collar ring over the upper end of the chain, through the (Finished side down). Then use another quick link to connect collar loop and the top of chain.
4. Lace the fixture wires, ground wires and safety cable through the chain and screw collar loop, exiting through the side of HICKEY. Proceed to attach the FIXTURE GROUND WIRE to HOUSE GROUND WIRE using wire connector. Using wire connectors, connect the HOUSE WHITE WIRE to the FIXTURE SUPPLY WIRE (WHITE OR RIBBED SIDE); connect the HOUSE BLACK (or RED) WIRE to the FIXTURE SUPPLY WIRE (BLACK or SMOOTH SIDE). Wrap all connectors with approved electrical tape. Wrap safety cable around outlet box brace and pull cable taut. Secure cable with the clamp and (2) set screws provided, as shown.
5. Push the CANOPY upward over the OUTLET BOX. Be sure that all wires are carefully tucked into the OUTLET BOX cavity. Secure canopy against ceiling by threading CANOPY LOCK RING onto the CANOPY LOOP. Tighten until snug.