ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DWC49

NAME: Gatsby Sconce

MATERIAL TYPE: Ricestine Composite


FINISH: Charcoal

SOCKET TYPE: LED SOCKET QTY: 1

BULB WATTAGE: LED 12W /2700K / 90+CRI

VOLTAGE: 110V-120V

ITEM NET WEIGHT: 7.7LBS





F Plastic wire connectors	K Anchor
TOOLS NEEDED(NOT INCLUDED) G. SCREWDRIVER	L Strengthen screw

PARTS INCLUDED:

Mounting Plate(A)	Qty:1	
Back Plate(B)	Qty:1	
Plate Screw(C)	Qty:2	

HARDWARE INCLUDED:

	Mounting Screws	Qty: 2PCS
Plastic Wire Connector Qty: 3PCS	Plastic Wire Connector	Qty: 3PCS

TOOLS NEEDED (Not Included):

1 Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.




TO ASSEMBLE:

- 1. Shut off the main electrical supply from the main fuse box/circuit breaker.
- 2. Attach mounting plate to wall or junction box using mounting screws (C).
- 3. Connect ground wire from wall to ground wire from lamp using wire caps (A).
- $4.\ \mbox{Attach}$ house wire to lamp wires as shown. Fasten the pairs together with a wire caps.

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

- Attach front face of light to back plate by inserting canopy screws (B) through predrilled holes in front face and into back plate as shown. Tighten using screwdriver.
- 6. Insert light bulb.
- 7. Restore power to junction box and test fixture.

DO NOT EXCEED SPECIFIED MAX WATTAGE.



CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIORS