

E26

ASSEMBLY INSTRUCTIONS

USA & CANADA

Â

WARNING!

Be sure electrical power is OFF before and during installation or maintenance. The luminaire must be installed by a qualified electrician, in accordance with all applicable local codes.

Ensure that the rated luminaire voltage requirements are compatible with the available mains supply in which it will be installed.

All LEDS are included in your lamp. Never touch the LED surface with your bear hands as this may reduce the life of your LED.

Do not alter, relocate or remove any electrical component

Family: Floor Lamp

Input Voltage: 120 - 277V Input Frequency: 60 Hz

Material: Natural Wood Veneer, MDF and Carbon Steel.




ASSEMBLING THE FIXTURE

Turn off the electrical power before starting the installation, and keep it turned off until the installation is completed.

This assembly may require the work of two people so it can be secure and well executed.

- 1) This luminaire is sent unassembled, and require attention to the procedures to guarantee proper assembly. Join the support rods, by screwing the lower rod (with the connector and nut at the tip) to the upper rod (with the socket at the tip).
- 2 Pass the connector, cable and nut to the larger hole at the base, and fit the threaded nipple in the smaller hole.
- 3 Tighten the nut to the threaded nipple, fixating the rod to the base, and make sure that the installation is tight and secured.
- (4) Join the connectors from the rod and from the power cord inside the luminaire's base.
- (5) Using the (P1) screws, tighten and close the cover of the support base.



ATENTION!

<u>(!</u>\

FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE ACCIDENTS AND LOSS OF PRODUCT WARRANTY. Its recommended to read these instructions completely and carefully before proceeding.

PROVIDED SCREWS

Ų

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ACCORD Lighting guarantees coverage against manufacturing defects including electrical components and finishes, for a period of three years, under normal use, from the date of purchase. For warranty service, please contact your local dealer for further instructions. Proof of date of purchase will be required for validation of warranty service.

The responsability of the manufacturer regarding the product warranty is related to the correct observation of the instructions contained in this manual. The manufacturer is not responsible for any damage to the product caused by accidents, alterations of any kind, improper usage or improper installation. See the website for additional warranty details.

ACCORD Lighting reserves the right to change the dimensions and specifications contained in this manual without prior notice, in accordance with its policy of continuous product improvement. Please, contact the manufacturer if additional information is necessary. The illustrations in this manual are for guidance only and may vary in scale, dimensions and model details.



E26

ASSEMBLY INSTRUCTIONS

USA & CANADA

Â

3059

WARNING!

Be sure electrical power is OFF before and during installation or maintenance. The luminaire must be installed by a qualified electrician, in accordance with all applicable local codes.

Ensure that the rated luminaire voltage requirements are compatible with the available mains supply in which it will be installed.

All LEDS are included in your lamp. Never touch the LED surface with your bear hands as this may reduce the life of your LED.

Do not alter, relocate or remove any electrical component.


REF. / Light bulb 3053 / 1x E-26 3054 / 1x E-26 3055 / 1x E-26 3057 / 1x E-26 3058 / 1x E-26

1x E-26

Family: Floor Lamp

Input Voltage: 120 - 277V Input Frequency: 60 Hz


Material: Natural Wood Veneer, MDF and Carbon Steel.



ASSEMBLING THE FIXTURE

- (a) To install the shade, unscrew the socket nut, and insert the shade into the socket.
- 7) Tighten the socket nut to lock the shade to the socket.
- (8) Install a E26 at the socket, with a maximum rating of 25W.
- (9) Use the switch on the power cord to turn the luminaire on/off.
- 10 Plug the luminaire to an appropriate outlet.

Your luminaire is ready for use.







ATENTION!



FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE ACCIDENTS AND LOSS OF PRODUCT WARRANTY. Its recommended to read these instructions completely and carefully before proceeding.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ACCORD Lighting guarantees coverage against manufacturing defects including electrical components and finishes, for a period of three years, under normal use, from the date of purchase. For warranty service, please contact your local dealer for further instructions. Proof of date of purchase will be required for validation of warranty service.

The responsability of the manufacturer regarding the product warranty is related to the correct observation of the instructions contained in this manual.

The manufacturer is not responsible for any damage to the product caused by accidents, alterations of any kind, improper usage or improper installation.

See the website for additional warranty details.

ACCORD Lighting reserves the right to change the dimensions and specifications contained in this manual without prior notice, in accordance with its policy of continuous product improvement. Please, contact the manufacturer if additional information is necessary. The illustrations in this manual are for guidance only and may vary in scale, dimensions and model details.