

PENDANT INSTALLATION INSTRUCTIONS

SALERNO AND PESCADERO OUTDOOR PENDANTS

PROFESSIONAL INSTALLATION REQUIRED

CAUTION: BEFORE INSTALLING FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

Important Safety Instructions:

- These instructions are provided for your safety. It is important that they are read carefully before use to ensure safe operation of the product.
- Installation by a licensed professional electrician required.
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- The lighting fixture is meant for outdoor use. It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
- For your safety, it is strongly recommended that two people install the lighting fixture.
- This fixture has been rated for up Two (2) 40 watt maximum E26 Type A bulbs or Two (2) 10 watt maximum LED bulbs (not included). To avoid the risk of fire, do not exceed the recommended lamp wattage.
- The lighting fixture is meant for outdoor use.
- Save these instructions.


WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.
- Check the cable properly for any loose or damaged connections.
- When the unit is no longer functioning, do not attempt to fix it by yourself. Only a qualified technician is allowed to disassemble and repair.
- If the external flexible cable cord of this luminaire is damaged it shall be exclusively replaced by a qualified electrician in order to avoid hazard.

Pre-Assembly:

- Remove all parts and hardware from the box along with any plastic protective packaging. Do not discard contents until
 after assembly is complete to avoid accidentally discarding small parts or hardware.
- · For your safety and convenience, assembly by two people is recommended

TOOLS REQUIRED (not included): Ladder, Phillips Head & Flat Blade Screwdrivers, Wire Cutter/Stripper & Electrical Tape.



Installation Instructions:

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Gently pull existing wires down from the ceiling junction box and allow them to hang.
- 3. Decide desired height of fixture and select Poles (F) as needed. Combine poles by rotating clockwise until tight. Thread wires loosely through canopy (E), threaded rod and mounting strip (A).
- 4. Attach mounting strip to ceiling junction box. Connect wiring here.
 - a) Connect the NEUTRAL FIXTURE WIRE to the NEUTRAL JUNCTION BOX WIRE (usually white or ribbed insulation). Fasten each together with a wire connector (C) and wrap the connection with electrical tape. Be sure that no wire strands are exposed.
 - b) Connect the HOT FIXTURE WIRE to the HOT JUNCTION BOX WIRE (usually black or smooth insulation). Fasten each together with a wire connector (C) and wrap the connection with electrical tape. Be sure that no wire strands are exposed. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
 - c) Connect the GROUND WIRE of the fixture to the GROUND J-BOX WIRE (usually green or bare) with a wire connector (C) and wrap the connection with electrical tape. Be sure that no wire strands are exposed. If there is no ground wire in the J-Box, use a screwdriver to secure the end of the fixture ground wire to the GROUND screw (D) located on the cross bar.
- 5. Slide loop assembly up and attach to threaded rod while holding cord to prevent twisting.
- 6. Slide canopy (E) up flush to ceiling and secure by twisting to the collar ring onto loop assembly.
- 7. Insert Two (2) 40 watt maximum E26 Type A bulbs or Two (2) 10 watt maximum LED bulbs (not included). into the socket. DO NOT EXCEED THE RECOMMENDED WATTAGE.
- 8. Insert diffuser ring (H) into the Fixture (G) by using diffuser screws (I1, I2, I3, & I4) an tighten one by one, untly they tight.
- 9. Remove Shade knobs (J) to attached Shade.
- 10. Restore power to ceiling outlet junction box and test fixture.
- 11. Installation is complete.

Care Instructions:

- Do not use abrasive cleaning solution as it may cause damage to the fixture's finish.
- Wipe clean with a soft, dry cloth or static duster.