

SUKI MINI TABLE LAMP

KST1231


General Product Information:



Intertek



WARRANTY



FCC STATEMENT




Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.

DO NOT INCINERATE.

The light source of this luminaire is not replaceable. When the light source reaches its end-of-life, the whole luminaire shall be replaced.





INSTRUCTIONS

1. Remove the fully assembled fixture from the packaging.
2. Plug-it in with the supplied USB cord and adapter plug.
3. Pay attention to the indicator light, located next to the USB-C port:
 - a) Solid Red: The fixture needs to be charged.
 - b) Green Flashing: The fixture is currently charging.
 - c) Solid Green: The fixture is fully charged.

Note:

- **Ensure that the product is fully charged before initial use, which will take approximately six hours.**
 - **Ensure that the silicone USB cover is reinstalled after charging to keep dust and moisture out of the plug area.**
4. Use the touch-sensitive switch to turn it on or to change the brightness setting.