
ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: 49924-711	NAME: Sidney Lamp	
MATERIAL TYPE: Marble	FINISH: Black	

SOCKET TYPE: E26 SOCKET QTY: 2

BULB WATTAGE: 60W/CFL 16W/LED 13W



PARTS INCLUDED:

Finial (A)	Qty: 1	
Shade (B)	Qty: 1	
Rod (C)	Qty: 1	
Bulb (D)	Qty:	
Wire Box (E)	Qty: 1	
Socket (F)	Qty: 2	
Knob(G)	Qty: 1	
PRE-ASSEMBL • Remove all parts and plastic protecting p	nd hardware from box along with any	
• Do not discard any	contents until after assembly is complete ly discarding small parts or hardware.	
to avoid accidental	y discarding smail parts or hardware.	

For customer service questions call 1-800-338-2150



TO ASSEMBLE:

1. Attach the rod (C) to the top of the socket cluster (E/F).

2. Twisting tightly clockwise, place the shade (B) on the top of rod (C).

3. Place the finial (A) onto rod (C) and tighten clockwise to secure shade (B).

4. Insert correct bulb (D) into the socket (F).

CARE INSTRUCTIONS:

- Clean with soft, dry cloth.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the lamp.

IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one polade is wider than the other) (For North America Customers Only). If the plug does not fit securely into your outlet, do not force it – contact a professional electrician. Use the plug with an extension cord poly if it can be fully inserted into the cord's socket. Never alter the plug in any way. This instruction is provided for your safety. It is important that it is read carefully and completely before assembling the fixture.

To avoid risk of fire, do not exceed the recommended wattage.

WARNING:

• To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing the bulb.

ARTERIORS

- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.