



ASSEMBLY INSTRUCTIONS FOR YOUR KANE TABLE LAMP

IMPORTANT SAFETY INSTRUCTIONS:

- *This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- *Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- *Switch power off and remove plug from the wall outlet before replacing the bulb.
- *This lamp is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

- 1.Unpack all parts and remove packing materials. Place lamp base on a level surface.
- 2.Remove finial (A) from harp (C). Squeeze harp (C) inward and place into the opening of saddle (D).
- 3.Place shade (B) onto harp (C). Thread finial (A) back onto the harp to secure the shade to the lamp.
- 4.Install one 150W max., type A, medium base bulb into the socket.
- 5.Remove protective plastic from plug (E).
- 6.Insert plug (E) into wall outlet.
- 7.Control power to the fixture by using the switch located on socket.

