## **ASSEMBLY INSTRUCTIONS**

#### ITEM DESCRIPTION:

ITEM NO.: DFC23 NAME:LOUISA FLUSH MOUNT


MATERIAL TYPE: METAL, ONYX FINISH: ANTIQUE BRASS, WHITE

SOCKET TYPE:LED SOCKET QTY: 1

BULB WATTAGE: 8.0W/2700K/90+CRI

VOLTAGE:100V-130V ITEM NET WEIGHT:2.20LBS

# PLEASE IGNORE THIS DEVICE IN THE LAMP BASE



### PARTS INCLUDED:

Mounting Plate (A)		Qty: 1 Pc	Plate screw (D)	Qty: 2 Pcs
Screw Nut	(B)	Qty: 2 Pcs	Onyx Disc (E)	Qty: 1 Pc
Lamp Base	(C)	Qty: 1 Pc	Metal Ring Cover (G)	Qty: 1 Pc

### HARDWARE INCLUDED:

Mounting Screws (J)	Qty: 2 Pcs
Plastic Wire Cap (K)	Qty: 3 Pcs

#### TOOLS NEEDED (Not Included):

1 Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.


We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.

For customer service questions call 1-800-338-2150



#### TO ASSEMBLE:

- Shut off the main electrical supply from the main fuse box/circuit breaker
- Attach mounting plate(A) to ceiling or junction box using mounting screws (J).
- 3. Connect ground wire from ceiling to ground wire from lamp using the wire caps (K).
- Attach house wire to lamp wires as shown. Fasten the pairs together with a wire caps(K). DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 5. PLEASE PAY SPECIAL ATTENTION THAT YOU DO NOT NEED TO CONNECT THE TERMINAL BLOCK (M) IN THE LAMP BASE. IT IS USED FOR THE WIRE CONNECTION FOR EUROMARKET.
- 6. Attach lamp base(C) to mounting plate (A) to through predrilled holes, then use screw nut (B) to tighten with plate screw (D) by turning in a clockwise direction.
- 7. Put and assemble the onyx disc (E) to the lamp base(C) with the metal ring cover (G) by turning in a clockwise direction.
- 8. Restore power to junction box and test fixture.



Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

ARTERIORS