




SAVOY
HOUSE

ITEM NO.: 11-CD24



INCLUDED:

LED lamp, USB to USB-C power cord. Wall adapter is not included.

Remove all components from packaging prior to disposing to ensure that all indicated pieces are provided.

USE

Charge the lamp before initial use.

1. Charge the lamp with the provided USB to USB-C charging cable.
2. Red light under the shade will illuminate while the lamp is charging. Red light will turn off when charging is complete.
3. When fully charged, disconnect the charging cable. Do not charge for more than 6 hours at a time.
4. The power button is located in the center of the shade. Touch the power button to illuminate. Touch and hold the power button to increase or decrease brightness.

LED memory will illuminate the lamp at the same brightness it was set to when it was last turned off. Lighting per charge: up to 8 hours.

Charging time: up to 6 hours.

Color temperature: 3000K, warm white, dimmable.

Rechargeable Lithium ion Battery: 3.7 V, 9.25wh, 2500mAh.