



SAVOY
HOUSE

ITEM NO.: 11-CD29

ASSEMBLY INSTRUCTIONS

Parts:

- A: Lamp body
- B: Harp
- C: Bulb
- D: Shade
- E: Finial

1. Carefully place all parts on a smooth surface and lay out in a line.
2. Place the lamp body (A) on a table.
3. Install bulb (C) (not included) into socket.
4. Squeeze legs of harp (B) together and insert them into the saddle.
5. Place shade (D) on top of harp (B) and secure it with finial (E).

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use it with an extension cord unless the plug can be fully inserted. Do not alter the plug.

