


ASSEMBLY & INSTALLATION INSTRUCTIONS

C129

Sway Floor Lamp 237681



HUBBARDTON FORGE.

MODERN AMERICAN BLACKSMITHS | FINE, HAND CRAFTED LIGHTING
CASTLETON, VERMONT USA | HUBBARDTONFORGE.COM

Component Parts

- A** **Fixture**
- B** **Bulb (*Not Included*)**
- C** **Socket**
- D** **Turn Knob**
- E** **Finial**
- F** **Harp**
- G** **Locks (2)**
- H** **Harp Holder**
- I** **Shade**




Sway Floor Lamp 237681

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Lamp Assembly (Figure 1)

1. Carefully unpack fixture (A).
2. Install bulb (B), not included, into socket (C).
3. Install turn knob (D) onto socket (C).
4. Finial (E) is shipped installed on harp (F). Remove finial (E) from harp (F) and retain for later use.
5. Squeeze harp (F) together while holding the locks (G) up towards the top of the harp and slip into harp holder (H).
6. Allow locks (G) to slip down harp (F) and onto harp holder (H) to secure harp (F) in place.
7. Set shade (I) onto threaded stud on top of harp (F).
8. Thread finial (E) onto threaded stud on harp (F) and tighten until snug. Be careful not to over tighten.
9. Plug in power cord.



(Figure 1)

If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!

* **Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.**