

# UTTERMOST

## ASSEMBLY INSTRUCTIONS

### STYLE NO.: 21575 PARTS LIST& HARDWARE LIST:

1	Canopy	1pc	7	Quick Link	2pcs
2	Universal Bar	1pc	8	5 Feet Chain	1pc
3	Outlet Box Screw(1-1/8")	2pcs	9	Ring	1pc
4	Green Ground Screw	1pc	10	Pin	9pcs
5	Mounting Screw(2-3/4")	2pcs	11	Glass Shade(A/B/C)	3pcs
6	Wire Connector	3pcs	12		

\*Please make sure you have all the parts indicated above before you begin assembling this item. We suggest a professional electrician for all lighting fixture installations. Please read wiring instructions before you begin assembling and installing your Ceiling Lamp

**WARNING:** Before installing, make sure electricity supply is shut off to avoid a possible electric shock.

## ASSEMBLY INSTRUCTIONS

1. Take the parts carefully out of the carton, Place them on a flat surface, and make sure the parts will not be damaged.
2. Fasten the Cross bar to the outlet box . Secure the Nipple onto the Canopy with Loop .
3. Adjust chain and wire length as needed. Thread Quick Link into Loop on the Canopy, then Quick Link into Loop on the top of Pendant body. Hand tighten until snug.
4. Pull the wire from the Canopy and then the center hole in the Cross Bar. The power supply wire consists of three wires, one black wire, one white wire and one green ground wire.
5. Connect the wires as shown :
  - A. Connect the House Ground Wire to the Fixture Ground Wire.
  - B. Connect the House White Wire to the Fixture Supply Wire (White ).
  - C. Connect the House Black Wire to the Fixture Supply Wire (Black ).
  - D. Wrap each connected wire with Wire Nut and carefully stuff all of the connected wires into the Outlet Box.
6. Install 3\*60W, E12 bulbs (Not Included) into the socket of the fixture.
7. Secure Glass shade (A/B/C) with pin on round metal sheet.

# UTTERMOST

## ASSEMBLY INSTRUCTIONS

