

UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE NO.: 21636 PARTS LIST& HARDWARE LIST:

1	Canopy	1pc	7	Quick Link	2pcs
2	Universal Bar	1pc	8	5 Feet Chain	1pc
3	Outlet Box Screw(1-1/8")	2pcs	9	Ring	1pc
4	Green Ground Screw	1pc	10	Finials	4pcs
5	Mounting Screw(2-3/4")	2pcs	11	Glass Shade	1pc
6	Wire Connector	3pcs	12		

***Please make sure you have all the parts indicated above before you begin assembling this item. We suggest a professional electrician for all lighting fixture installations. Please read wiring instructions before you begin assembling and installing your Ceiling Lamp**

WARNING: Before installing, make sure electricity supply is shut off to avoid a possible electric shock.

ASSEMBLY INSTRUCTIONS

1. Take the parts carefully out of the carton, Place them on a flat surface, and make sure the parts will not be damaged.
2. Fasten the Cross bar to the outlet box .Secure the Nipple onto the Canopy with Loop .
3. Adjust chain and wire length as needed, remove excess. Thread Quick Link into Loop on the Canopy, then Quick Link into Ring on the top of Pendant body. Hand tighten until snug.
4. Install 1*60W, E26 bulb type-A(Not Included) into the socket of the fixture.
5. Hold up Glass Shade, make sure top side edge hole is align with hole on the metal cap, secure it with Finials.
6. Pull the wire from the Canopy and through the center hole in the Cross Bar. The power supply wire consists of three wires, one black wire, one white wire and one green ground wire.
7. Connect the wires as shown :
 - A. Connect the House Ground Wire to the Fixture Ground Wire.
 - B. Connect the House White Wire to the Fixture Supply Wire (White).
 - C. Connect the House Black Wire to the Fixture Supply Wire (Black).
 - D. Wrap each connected wire with Wire Nut and carefully stuff all of the connected wires into the Outlet Box.

UTTERMOST

ASSEMBLY INSTRUCTIONS

DO NOT EXCEED THE MAXIMUM WATTAGE RATING!

