


GUBI


ASSEMBLY INSTRUCTIONS

for

Hornbæk Portable Lamp




CONTENTS



x1



x1



x1



x1




x1




x1

1.

a)
Attach the metal frame to the ceramic base.
Align the threads and turn them clockwise to
tighten the structure.



b)
Install the light bulb into the socket.




Note: GUBI cannot vouch for the light and
battery efficiency of other light bulbs. If you
need a new light bulb, please contact GUBI.

2.


a)
Unpack the shade.

b)
To prepare it, fold in the edges to create a three-dimensional structure. The shape will remain in position after installation.

a)



b)






3.

Hold the shade in the two bottom tips to guide it into the metal frame.

a)
Ensure that both edges of the shade are inserted into the guide rail.



b)
Pull the shade all the way down.

c)
The shade will reach its position when it hits the stop.




4.

Activate and adjust the light by touching the bean shaped area on the LED-module.




5.

During use battery capacity will be indicated on LED-module.
When indication light is glowing steady: Battery power is above 20%
When indication light is calmy breathing: Battery power is below 20% and should be charged in time.



6.

When charging, place the lamp on the charging base. Lamp is connected when you see the light on the front beginning to breathe quietly up and down.
When the battery is fully charged, the light will go off.





CARE INSTRUCTIONS

Daily cleaning can be done by wiping the frame with a clean dry cloth. Should the surface need more attention this can be cleaned with water and a light detergent or soap applied with a damp cloth. Wipe after with a clean dry cloth. Avoid any abrasive materials.

TROUBLESHOOTING

If lamp does not light, turn off the power. Try charging the product to 100%. Check the bulb for a broken filament. Replace bulb if necessary, then turn it on. If the lamp still does not light, please contact customer service at the local dealer. If the charging cable for this lamp is damaged, it must be replaced in order to avoid a hazard.

TECHNICAL INFORMATION

Light source: LED Bulb (DC), 250 Lumen (3W LED). Lightsource can be purchased through GUBI.
Turn power off when changing light bulb. Isolation class III. The lamp is approved for outdoor use in damp/wet rooms (IP44)

ENVIRONMENTAL PROTECTION

Electrical products must NOT be thrown out with domestic waste. They must be taken to a communal collecting point for environmentally friendly disposal in accordance with local regulations. Contact your local authorities or retailer for advice on recycling. The packaging material is recyclable. Dispose of the packaging in an environmentally friendly manner and make it available for recyclable material collection-service. Do not incinerate.



For enquiries contact GUBI A/S - CVR: 17940384
Orientkaj 18-20. 2150 Nordhavn. Copenhagen, Denmark
T +45 69 15 60 60 – order@gubi.com
GUBI.COM