

# INSTALLATION INSTRUCTION

## Step and Wall Light

4011



### WARNING

IMPORTANT: NEVER attempt to do any work without shutting off the electricity.

- Read all instructions before installing.
- System is intended for installation by a qualified electrician in accordance with the National Electrical Code and local regulations.
- Place the wall switch in the "OFF" position.
- Go to the main fuse box, or circuit breaker. Unscrew the fuse(s) or switch "OFF" the circuit breaker switch(es) that control the power to the space that you are working on.
- Listed wire nuts for wet location

### CAUTION

- All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to follow this instruction may invalidate the UL/CUL listing of this fixture.

**JUNCTION BOX:** 2" x 4" boxes to have minimum inside dimensions of 3"H x 2"W x 2"D in order to accommodate fixtures.

**Note:** Actual depth of box to be determined in accordance with the NEC and local ordinances. Indoor or outdoor frame mounted junction box: Raco 2" x 4" (16.5 cu. In) or equivalent recommended. Outdoor surface mounted junction box: Red Dot deep weatherproof box Model S103E or equiv. recommended. Mortar or poured concrete installation: Use appropriate junction box suitable for that particular application

### AVERTISSEMENT

IMPORTANT : Coupez l'électricité avant TOUTE manipulation.

- Lisez toutes les instructions avant d'installer.
- Système est destiné à être installé par un électricien qualifié en conformité avec le code national de l'électricité et les règlements locaux.
- Placez l'interrupteur mural en position d'arrêt (« OFF »).
- Toujours mettre le fusible ou le disjoncteur en position arrêt dans la pièce où des travaux électriques sont prévus

### MISE EN GARDE

- Toutes les pièces doivent être utilisées tel qu'il est indiqué dans ces instructions. Ne remplacez pas les pièces, n'en laissez pas de côté et ne les utilisez pas si elles sont usées ou brisées. Le non-respect de ces instructions peut annuler l'homologation UL /CUL du luminaire.

**BOITE DE JONCTION:** boîtes de 2"x4" pour avoir des dimensions intérieures minimales de 3"H x 2"W x 2"D pour accueillir les luminaires.

**Note:** Profondeur réelle de la boîte à déterminer conformément à la NEC et les ordonnances locales. Cadre intérieur ou extérieur monté Boîte de jonction: Raco 2"x4" (16,5 cu. In) ou équivalent recommandé. Boîte de jonction extérieure montée en surface: Red Dot deep Boîte résistant aux intempéries Modèle S103E ou équiv. conseillé. Installation de mortier ou de béton coulé: utiliser une boîte de jonction appropriée Convient à cette application particulière

### ADVERTENCIA

IMPORTANTE: NUNCA intente hacer trabajos sin desconectar el suministro eléctrico.

- Lea y comprenda todas las instrucciones e ilustraciones por completo antes de proceder con el ensamblaje e instalación de esta lámpara.
- Sistema está diseñado para ser instalado por un electricista calificado, de acuerdo con el código eléctrico nacional y las normas locales.
- Coloque el interruptor de la pared en la posición "OFF" (APAGADO).
- Diríjase a la caja de fusibles o a la caja del interruptor de circuito principal en su hogar. Coloque el interruptor de alimentación principal en la posición "OFF" (APAGADO).

### PRECAUCIÓN

- Todas las piezas deben usarse como lo indican estas instrucciones. No reemplace las piezas, no omita piezas durante la instalación ni utilice piezas gastadas o rotas. El incumplimiento de esta indicación podría invalidar la calificación UL/CUL esta lámpara.

**JUNCTION BOX:** Cajas de 2"x4" para tener dimensiones interiores mínimas de 3"H x 2"W x 2"D para acomodar los accesorios.

**Nota:** La profundidad real de la caja se determinará de acuerdo con el NEC y las ordenanzas locales. Montado en el marco interior o exterior Caja de empalmes: Raco 2"x4" (16.5 pulgadas cúbicas) o equivalente recomendado. Caja de conexiones montada en superficie: Red Dot deep Resistente a la intemperie Modelo S103E o equivalente. recomendado. Instalación de mortero o de hormigón vertido: Usar caja de empalmes apropiada Adecuado para esa aplicación en particular

### MOUNTING ACCESSORIES (INCLUDED IN BOX)

*\*Note: Transformer is required to power the fixture. (sold separately)*




Rubber Washer  
7MPH0704C1BK  
Qty: 2pcs



Mounting Screw  
7MPF0416C6  
Qty: 2pcs



Wire Nut  
7EAC000253  
Qty: 2pc



Mounting Bracket  
7MBC964501  
Qty: 1pc



Junction Box Screw  
7MPF0308S1  
Qty: 2pc

wacighting.com  
Phone (800) 526.2588  
Fax (800) 526.2585

Headquarters, East Manufacturing Facility  
44 Harbor Park Drive  
Port Washington, NY 11050

South East Manufacturing Facility  
1600 Distribution Ct  
Lithia Springs, GA 30122

Central Manufacturing Facility  
1700 South J Elmer Freeway, Ste 100  
Cedar Hill, TX 75104

West Manufacturing Facility  
1750 S Archibald Ave  
Ontario, CA 91761

# INSTALLATION INSTRUCTION

## Step and Wall Light

4011




WAC  
LANDSCAPE LIGHTING®

### STEP 1: DETERMINE MOUNTING POSITION

*\*Note: Transformer is required to power the fixture. (sold separately)*

1. Make sure the main power supply to your transformer is turned off.
2. Install a 2" by 4" junction box, and ensure it is water-tight for outdoor use.
3. Secure the mounting bracket to the junction box using two 8-32 junction box screws.
4. Connect the fixture wires to the landscape wires from the transformer using the wire nuts provided.
5. Place all wiring and connectors back in the junction box.
6. Use the rubber washer and mounting screw to install and secure the fixture to the mounting surface.

**Note: For outdoor installation, it is required that the installer run a bead of outdoor-rated silicone caulk (provided by others) between gasket or back of fixture and mounting surface to prevent seepage of water into fixture.**



wacighting.com  
Phone (800) 526.2588  
Fax (800) 526.2585

Headquarters, East Manufacturing Facility  
44 Harbor Park Drive  
Port Washington, NY 11050

South East Manufacturing Facility  
1600 Distribution Ct  
Lithia Springs, GA 30122

Central Manufacturing Facility  
1700 South J Elmer Freeway, Ste 100  
Cedar Hill, TX 75104

West Manufacturing Facility  
1750 S Archibald Ave  
Ontario, CA 91761