



1718 W. Fullerton Chicago, IL 60614  
 Ph: 773,770,1195 • Fax: 773,935,5613  
 www.PureEdgeLighting.com • info@PureEdgeLighting.com  
 © 2016 PureEdge Lighting. All Rights Reserved.


## Installation Instructions for **Reveal Wall Wash 2 L-Shaped Inside and Outside Corner Channel Connector**

RVWW2-L\_ \_


### IMPORTANT INFORMATION

- This instruction shows a typical installation.
- Reveal Wall Wash must be mounted 24" away from the wall.
- This instruction must be used concurrently with other Reveal Wall Wash 2 DIY installation instructions.
- This product is ceiling mount only.

**SAVE THESE INSTRUCTIONS!**




LO



LI




### Section One: Install the Corner Channel Connector




#### Inside Corner Channel Connector:

- 1:** Place the Inside Corner Connector against the ceiling. Ensure the Inside Corner Connector is aligned with the Reveal Wall Wash Channel installation location.
- 2:** Mark the installation location of the connector on the ceiling using a pencil or chalk line before cutting.

- 3:** Slide the Reveal Wall Wash channel onto the channel joiners of the Inside Corner Connector.
- 4:** Repeat step 3 for the other end of the Inside Corner Connector.







**Outside Corner Channel Connector:**

- 5:** Place the Outside Corner Connector against the ceiling. Ensure the Outside Corner Connector is aligned with the Reveal Wall Wash Channel installation location.
- 6:** Mark the installation location of the connector on the ceiling using a pencil or chalk line before cutting.

- 7:** Slide the Reveal Wall Wash channel onto the channel joiners of the Outside Corner Connector.
- 8:** Repeat step 7 for the other end of the Outside Corner Connector.



- 9:** Follow steps described in the Reveal Wall Wash Channel and Lens installation instructions to complete the installation.