

**SAFETY INFORMATION**

Released Date: 2023-11-01

Please read and understand this entire manual before attempting to assemble, install or operate the product.


**WARNING**

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.

**CAUTION**

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.

**TOOLS REQUIRED**




Ratings	120Vac, 60Hz	
	Model No.	Wattage
	PCGRC8520C	20W
	PCGRC8527C	30W

**CARE AND MAINTENANCE**

- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.


If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at [www.quoizel.com](http://www.quoizel.com).

**PACKAGE CONTENTS**



**A** Fixture Body  
x 1

**MOUNTING HARDWARE**



**AA** Crossbar  
x 1



**BB** Mounting Screw  
x 4



**CC** Wire Connector  
x 3




**DD** Outlet Box Screw  
x 2

INSTALLATION

1


Install Inner Backplate



Outlet Box

2

Wiring



White wire from supply      White wire from fixture


Black (or red) wire from supply      Black wire from fixture

Ground wire from supply      Ground wire from fixture

Green ground screw

3

Install Fixture Body



Your installation is now complete! Restore electricity and save this sheet for future reference.