

SAFETY INFORMATION

Released Date: 2023-10-11

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS



A Ceiling Canopy
x 1



B Glass Shade
x 1



C Big Flat Washer
x 1



F Rubber Washer
x 2



D Small Flat Washer
x 1



G Hex Nut
x 1




E Stem with Hex Nut
x 1



H Finial
x 1

MOUNTING HARDWARE



AA Crossbar Assembly
x 1



BB Wire Connector
x 3




CC Outlet Box Screw
x 2

INSTALLATION


1

Install Crossbar Assembly




2

Wiring




3

Install Ceiling Canopy



4

Install Stem with Hex Nut





5

Install Bulbs


Install two correct bulbs referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):



6

Install Glass Shade and Finial



Your installation is now complete! Restore electricity and save this sheet for future reference.