



SAFETY INFORMATION

Released Date: 2023-10-07

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED



CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184(9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com


PACKAGE CONTENTS




A Fixture Loop
X 1



B Fixture Body
X 1



AA Crossbar Assembly
X 1



BB Wire Connector
X 3




CC Outlet Box Screw
X 2



DD Quick Link
X 2




EE Fixture Chain
X 1




FF Ceiling Canopy
X 1

INSTALLATION


1 Remove Polyfoams



2 Install Fixture Loop



3 Install Crossbar Assembly




4 Install Fixture Chain




OPTIONAL: Adjust Chain as desired, using pliers and soft cloth (neither included).

Suggested chain length for Ceiling height:
8 feet ceiling: use 1 link of chain and 2 quick links
9 feet ceiling: use 11 links of chain and 2 quick links
10 feet ceiling: use 21 links of chain and 2 quick links.




5 Pull Supply Wires


Pull the supply wires with ground wire through the chain alternate links.



6 Wiring



7 Install Ceiling Canopy





INSTALLATION

8 Install Bulb

Install one correct bulb referring to fixture markings and/or labels for maximum wattage.


Recommended Bulb Type (not Included):



Your installation is now complete! Restore electricity and save this sheet for future reference.

HOW TO REPLACE GLASS PANEL

1 Remove GLASS PANELS



Reverse above steps to reinstall the replacement Glass panels onto fixture.