JOSHUA TREE G4 Path Light




DESCRIPTION

The Joshua Tree Path Light comes complete with one or two G4 Rectangular Wafer sockets. This modern fixture is a downward facing path light perfect for path, area, and garden accent lighting.

JOSHUA TREE PATH LIGHT

Use	Path, Area, and Garden Accent Lighting		
Finish	Black Aluminum (Cerakote®)		
Includes	ABS Mounting Stake, LightingShrink Professional Crimp, and Heat Shrink Cable Connector		
Order With Lamp	G4 Rectangular Wafer	1 socket, 2700K, 120 Lumens 2 sockets, 2700K, 240 Lumens	JOSHUA-PL-20-G4-1-AL-BLK JOSHUA-PL-20-G4-2-AL-BLK
Order Without Lamp	Fits G4 Bi-Pin	1 socket 2 sockets	JOSHUA-PL-20-G4-1-AL-BLK-NL JOSHUA-PL-20-G4-2-AL-BLK-NL



Black Aluminum + Cerakote® (AL-BLK)



JOSHUA-PL-20-G4-2-AL-BLK

SOFT SOIL APPLICATIONS: INSTALLING THE GROUND STAKE & FIXTURE

- 1. Connect the power cable from the fixture body to the landscape cable.
- 2. Lay the power cable into the slotted relief on the stake.
- 3. Press the fixture and stake into the ground.
- 4. Use a level to ensure the top of the stake is level with the ground.

HARD SOIL APPLICATIONS: INSTALLING THE GROUND STAKE & FIXTURE

- 1. Unscrew the fixture body from the stake.
- 2. Dig a hole approximately 4" wide by 10" deep and gently tap the stake into the ground with a rubber mallet.
- 3. Use a level to ensure the top of the stake is level with the ground.
- 4. Reinstall the fixture body onto the stake and lay the power cable into the slotted relief on the stake.
- 5. Connect the power cable from the fixture body to the landscape cable.

INSTALLING THE LAMP

- 1. Loosen the set screw for the lens cover.
- 2. Remove the aluminum lens cover.
- 3. Install the G4 Wafer into the socket.
- 4. Place the lens cover back on the fixture body.