

Dual dimmer/countdown timer switch

(two loads)



Dimmer (top)

- Tap on to favorite light level; tap off; tap twice for full on
- Touch rocker to adjust light level
- Dimmer advanced programming features available

Timer switch (bottom)

- Tap on to start timer; tap off; tap twice for untimed on
- Touch rocker to adjust countdown time from 5–60 minutes
- One minute warning before lights go off
- Top LED is full on with no timer action
- Single location only
- Timer advanced programming features available

Companion dimmers



- For true multi-location dimming from every location; use up to nine companion dimmers with only one Maestro multi-location dimmer
- Use standard single-pole and 3-way wiring

Companion controls

Companion dimmers

Companion dimmer 120V	MA-R- XX ²
Companion dimmer 120V	MSC-AD- XX ³
Companion dimmer 277V	MA-R-277- XX ²
Companion dimmer 277V	MSC-AD-277- XX ³

No derating required if ganged.

Incandescent/halogen dimmer and timer switch**

Dual dimmer/timer switch (two loads)

Single-pole 120V 300W light (top) Incandescent/halogen 2.5A timer switch (bottom) Lighting load and/or general purpose fan(s)	MA-L3T251- XX ¹
---	-----------------------------------

XX¹: Gloss and Satin Colors® codes, see pg. 50
XX²: Gloss color codes, see pg. 50
XX³: Satin Colors codes, see pg. 50
 (Wallplates not included. Order separately, see pg. 169)

All models must be derated if ganged unless otherwise noted, see pg. 179.

**Minimum load required, see specification submittal.