EDGE LIGHTING

1718 W. Fullerton Ave
Chicago, IL 60614
Tel: 773-770-1195
Fax: 773-935-5613
www.edgelighting.com
info@edgelighting.com

© 2017 Edge Lighting. All Rights Reserved.

BLOCCO-C-30W-30K-___

**COUPE-C-30W-30K-___**

ETL LISTED
C US
Intertek

## Installation Instructions for **Blocco and Coupe LED**

IMPORTANT INFORMATION
- This product is ETL listed for indoor dry locations.
- This product is ceiling-mount only.
- This product can be dimmed with an electronic low voltage dimmer.

SAVE THESE INSTRUCTIONS!

Install the Mounting Plate and Housing

A

MOUNTING PLATE

M4 SET SCREW

FIXTURE

**COUPE (3 SET SCREWS)**

BLOCCO (4 SET SCREWS)

NOTE: Before beginning any electrical work, ensure that power to the junction box is turned **OFF**.

1: Loosen the M4 set screws using the 2mm Allen wrench.

2: Remove the mounting plate from the fixture.

B

MOUNTING ADAPTER

M4 SET SCREW

3: If required, secure the mounting adapter to the electrical holes with the two #8-32 screws provided.

C

CEILING

MOUNTING PLATE

#6-32 SCREW (2x)

4: Feed the power wires through the center hole of the mounting plate and secure the plate to the mounting adapter using supplied 6-32 screws.

1

D

CEILING

⑤ ⑥ ──WIRE NUT

5: Connect the black 120VAC hot wire to the black wire from the fixture power supply using a wire nut.

6: Connect the white 120VAC neutral wire to the white wire from the fixture power supply using a wire nut.

E

⑦ CEILING

M4 SET SCREW

MOUNTING PLATE

FIXTURE ──→

NOTE: Contains integrated LED consuming a total of 30 Watts

7: Place the fixture to the mounting plate and secure by tightening the M4 set screws using a 2mm Allen wrench.

F BLOCCO

⑧

LENS

8: If necessary, rotate and tilt the lens assembly.

NOTE: Lens assembly rotates 360° and tilts maximum 20°.

COUPE

⑧

LENS