


1718 W. Fullerton Ave Chicago, IL 60614 Tel: 773-770-1195 Fax: 773-935-5613 www.edgelighting.com info@edgelighting.com

# Installation Instructions for Pix Stick Tie Stix Suspension 2-Light, 3-Light, 4-Light and 5-Light with Power

#### **IMPORTANT INFORMATION**


- This product is suitable for indoor locations.
- This instruction shows a typical installation.
- $\mathsf{PX5P}$  is shown for demonstration purposes.
- It is recommended more than one person assist in this installation.


## SAVE THESE INSTRUCTIONS!




**PX P-TX-** -


#### Section One: Install the Canopy








### Section Two: Install the Fixture



- **1:** Push each cable from the channel through the cord grips on the canopy. Ensure the cables are installed directly across from each other on the canopy.
- **2:** Adjust the fixture height by pushing the tab on the cord grip to slide the fixture up and down. Release the tab to lock the cable in place. Stagger the height of the channel, if needed.
- **3:** Trim excess cable, leaving about 1' of cable inside to finish electrical connections.

**NOTE:** If cable is curled or kinked, straighten by holding between the shaft of a screwdriver and thumb and pulling the cable through.



**4:** Use the #16 gauge hole of the AWG wire strippers to strip 1/2" of the outer plastic insulation from the cables.

