


Proceed with assembling following the operations in progressive numerical order.
Il faut procéder à le montage exécutant les opérations par l'ordre numérique progressif.

The safety of the appliance is granted only if it is properly used according to the following instructions. Which are to be kept. RM Ø94mm Ø3 11/16"

Always disconnect from the power supply before installing or performing any maintenance operations.

La sécurité de cet appareil n'est garantie que si l'on respecte
les instructions suivantes



D27 F49 RM 00/01-F43 RM 00-F44 RM 35
F39 RM 00 -F31 RM 00/01-F54 RM 00/01
F40 RM 35-F37 RM 00/01-F59 RM 00/01
(LED 500mA 16W)

Proceed with assembling following the operations in progressive numerical order.
Il faut procéder à la montage exécutant les opérations par l'ordre numérique progressif.

ATTENTION
The safety of the appliance is granted only if it is properly used according to the following instructions. Which are to be kept.

WARNING

Always disconnect from the power supply before installing or performing any maintenance operations.

Make attention not to exceed the maximum watts of the appliance

WIRING INSTRUCTIONS

1-Strip the wire coming from the junction box and from the fixture
twist them together with the white wires, insert a connector and twist tightly

2-Do the same procedure for the black wire

3-If the cable coming from the structure is flat strip the lined or rubbed wire,
twist it with the white wire, insert a connector and twist tightly

4-Strip the yellow and green wire, twist them together,
insert a connector and twist tightly

ATTENTION

La sécurité de cet appareil n'est garantie que si l'on respecte

les instructions suivantes

Par conséquent, il est important de les conserver soigneusement.

INSTRUCTIONS DE MONTAGE



1- Dénuder les fils provenant de la boîte de jonction et de la structure, enrouler
les fils blancs entre eux, introduire un connecteur et tordre avec force.

2- Effectuer la même opération avec le fil noir.

3- Si le câble de la structure est du type plat, dénuder le fil avec la règle ou la
salière, l'enrouler avec le blanc, introduire un connecteur et tordre avec force.

4- Dénuder les fils de terre jaune et vert, les enrouler entre eux, introduire un
connecteur et tordre avec force.

NC 3 1/2"



D27 F37 NC 00/01 - F49 NC 00/01 - F54 NC 00 - F43 NC 00 - F44 NC 00 -
F39 NC 00 - F40 NC 35 - F59 NC 00 - F31 NC 00/01

(LED 500mA 16W)

Proceed with assembling following the operations in progressive numerical order.
Il faut procéder à la montage exécutant les opérations par l'ordre numérique progressif.

ATTENTION

The safety of the appliance is granted only if it is properly used according to the following instructions. Which are to be kept.

WARNING

Always disconnect from the power supply before installing or performing any maintenance operations.

Make attention not to exceed the maximum watts of the appliance

WIRING INSTRUCTIONS

1-Strip the wire coming from the junction box and from the fixture
twist them together with the white wires, insert a connector and twist tightly

2-Do the same procedure for the black wire

3-If the cable coming from the structure is flat strip the lined or rubbed wire,
twist it with the white wire, insert a connector and twist tightly

4-Strip the yellow and green wire, twist them together,
insert a connector and twist tightly

ATTENTION

La sécurité de cet appareil n'est garantie que si l'on respecte
les instructions suivantes

Par conséquent, il est important de les conserver soigneusement.


INSTRUCTIONS DE MONTAGE

1- Dénuder les fils provenant de la boîte de jonction et de la structure, enrouler
les fils blancs entre eux, introduire un connecteur et tordre avec force.

2- Effectuer la même opération avec le fil noir.

3- Si le câble de la structure est du type plat, dénuder le fil avec la règle ou la
saiillie, l'enrouler avec le blanc, introduire un connecteur et tordre avec force.

4- Dénuder les fils de terre jaune et vert, les enrouler entre eux, introduire un
connecteur et tordre avec force.



D27 F37 IC 00/01 - F49 IC 00/01 - F54 IC 00 - F43 IC 00 - F44 IC 35 -
F39 IC 00 - F40 IC 35 - F59 IC 00 - F31 IC 00 - F31 IC 00/01
(LED 500mA 16W)