




— HUE serial number



User manual Notice d'emploi Manual do usuario


























- Check if the electrical specification on the product label is in accordance with the electrical socket
- Vérifiez si les spécifications électriques sur l'étiquette du produit sont conformes à la prise électrique
- Compruebe si la especificación eléctrica en la etiqueta del producto está de acuerdo con la toma de corriente


















Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807, USA

Signify Canada Ltd./Signify Canada Ltée. 281 Hillmount Road.

Markham ON Canada I 6C 2S3

Questions or Comments / Questions ou commentaires :

1-800-555-0050

Importado y/o distribuido en México por:

Signify Mexico S.A. De C.V.

Av I a Palma No 6

La Herradura, Huixquilucan,

Edo de México, C.P. 52784, México – R.F.C. PME-620620-E84

Centro de contacto: 01-800-508-9000

© 2021 Signify Holding All rights reserved www.philips-hue.com

4422 955 26021 Last update: 07/2021