

Installation Guide

MAGMA WALL LIGHT

Thoughtful lighting, responsibly designed in London.


Thank you for making the switch to Tala.
Discover the full Tala family at tala.co.uk

BEFORE STARTING

Please read instructions thoroughly before installation and keep them for future reference.

Please take extreme care when dealing with electrical equipment.

Improper assembly can undermine the safety and longevity of the product.



IMPORTANT

This light fitting must be connected to the supply earth. If your lighting circuit does not have an earth, ask a qualified electrician to provide an earth facility. This fitting operates on 120V mains voltage.

This product is for indoor use only.

WARNING

Always switch off electricity supply at the mains during installation and maintenance. We recommend that the fuse is withdrawn or the circuit breaker is switched off whilst work is in progress. Do not just turn off at the wall switch. All fittings must be installed in accordance with current NFPA 70, National Electrical Code (NEC).


RECOMMENDED EQUIPMENT

- Small flat head screwdriver
- Philips head screwdriver
- Wire strippers






Further equipment may be required for fixing to your wall or ceiling

Please visit our website to see our recommended dimmers.

Magma Wall Light - Provided Components




- (A) x1 Wall/Flush Mount light
- (B) x1 Wall/Ceiling bracket
- (C) x1 End Cap
- (D) x4 Faceplate Bolts
- (E) x5 Bulb
- (F) x1 Glass
- (G) x3 Connectors
- (H) Wall/Ceiling screws
(Always use screws and plugs that are appropriate to your wall/ceiling fixing)



STEP 1

First identify your household wiring using current NFPA 70, National Electrical Code (NEC). Attach the wall light wiring to your household supply as shown. Use an appropriate connectors.


Ensure all wiring connections are made inside the wall before wall bracket (B) is attached.




STEP 2

Attach (B) to your wall or ceiling using screws and plugs (H).

Always use screws and plugs that are appropriate to the ceiling/ wall type.






STEP 3


Align part (A) onto part (B) .


Secure with the bolts (D)



STEP 4

Insert the bulbs (E) into the lampholders and rotate clockwise until tight.





STEP 5

Position the Glass Disk (F) onto the fixture.

Hand-screw the End Cap (C) onto the fixture tightly to secure the Glass.

CARE AND CLEANING

We recommend cleaning with a soft dry cloth.

Do not use abrasive materials as these will damage the finish of the product. Do not use alcohol or other solvents.

WARRANTY AND AFTER-CARE

This product has a two-year warranty. If there appears to be a functional defect with the product during this time, please contact our team at customerservice@tala.co.uk.

Please note, if the cable attached to this fixture is damaged, it should only be replaced by qualified person.

Join the Community

hello@tala.co.uk | Instagram: @tala | Facebook: talaHQ | Pinterest: TalaLED | Tag: lighttoliveby

Tala Studios, 25B Vyner Street, London E2 9DG

Tala North America Inc. C/O LH Frishkoff & Company, 546 5th Avenue, FL 9
New York NY 10036