Cirque Small (LED)

700CQS_-LED, 700OWCQS_-LED 1.9

T E C H L I G H T I N G ®

GENERAL PRODUCT INFORMATION:

These fixtures are intended to be installed utilizing NEC compliant junction boxes.

c **ETL** us
LISTED
Intertek

This product is suitable for damp or wet locations.

This product can be dimmed with a low-voltage electronic dimmer.

This product may be ceiling or wall mounted.

This instruction shows a typical installation.

CAUTION - RISK OF FIRE
This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
Use minimum 90°c supply conductors.

Install the Fixture Base

1A

FIXTURE BASE
#6-32 SET SCREWS
1
2
1/16 ALLEN WRENCH
GLASS SHADE

1 While supporting the glass shade, loosen **(Do Not Remove)** all the #6-32 set screws on fixture base with the 1/16 Allen wrench.

**2** Carefully remove the glass out of the fixture base.

1B

3 Remove the mounting plate from the fixture base by unscrewing the two knurled nuts.

1C

MOUNTING PLATE
4 **4**
#8-32 SCREW   #8-32 SCREW

**4** Secure the mounting plate to the electrical box with 2 #8-32 screws.

NOTE: Install the mounting plate so that the studs are parallel or perpendicular to the walls, this will ensure that the fixture is oriented to the room.

1D

5 Ground the mounting plate in accordance with local electrical codes.

6 Connect the black fixture wire to the hot power line wire with a wire nut.

**7** Connect the white fixture wire to the neutral power line wire with a wire nut.

1E

8 Properly place all wires and wire nut connections into the electrical box, mount the fixture base to the ceiling by reinstalling it onto the mounting plate, and secure it tightly with the knurled nuts.

1F

9 **For wet location installation,** caulk around the fixture base with waterproof construction sealant.

Install the Shade

2A

FIXTURE BASE   #6-32 SET SCREWS

1

2

GROOVE ON
GLASS SHADE   1/16 ALLEN
                                              WRENCH

1 Place the glass shade into the fixture base until the grooved section of the glass shade is completely inside.

2 Hold the glass shade in place and tighten all the #6-32 set screws with the 1/16 Allen wrench to lock the glass shade in place.

SAVE THESE INSTRUCTIONS!

TECH LIGHTING®

7400 Linder Ave, Skokie, IL 60077
847.410.4400
www.techlighting.com

A Generation Brands Company

Cirque Large (LED)

TECH LIGHTING®

GENERAL PRODUCT INFORMATION:

These fixtures are intended to be installed utilizing NEC compliant junction boxes.

c **ETL** us
LISTED
Intertek

This product is suitable for damp or wet locations.

This product can be dimmed with a low-voltage electronic dimmer.

This product may be ceiling or wall mounted.

This instruction shows a typical installation.

Install the Fixture Base

1A

FIXTURE BASE
#6-32 SET SCREWS
**1**
2
GLASS SHADE
1/16 ALLEN WRENCH

1 ▷ While supporting the glass shade, loosen **(Do Not Remove)** all the #6-32 set screws on fixture base with the 1/16 Allen wrench.

**2** ▷ Carefully remove the glass out of the fixture base.

1B

MOUNTING PLATE
KNURLED NUT

3 ▷ Remove the mounting plate from the fixture base by unscrewing the two knurled nuts.

CAUTION - RISK OF FIRE
This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
Use minimum 90°c supply conductors.

**1C**

4
4
#8-32 SCREW
MOUNTING PLATE

4 ▷ Secure the mounting plate to the electrical box with 2 #8-32 screws.

NOTE: Install the mounting plate so that the studs are parallel or perpendicular to the walls, this will ensure that the fixture is oriented to the room.

1D

MOUNTING PLATE

#8-32 SCREW

5 Ground the mounting plate in accordance with local electrical codes.

6 Connect the black fixture wire to the hot power line wire with a wire nut.

7 Connect the white fixture wire to the neutral power line wire with a wire nut.

1E

KNURLED NUT

8 Properly place all wires and wire nut connections into the electrical box, mount the fixture base to the ceiling by reinstalling it onto the mounting plate, and secure it tightly with the knurled nuts.

1F

9 **For wet location installation,** caulk around the fixture base with waterproof construction sealant.

Install the Shade

2A

FIXTURE BASE

#6-32 SET SCREW

1

2

GROOVE ON GLASS SHADE

1/16 ALLEN WRENCH

1 Place the glass shade into the fixture base until the grooved section of the glass shade is completely inside.

2 Hold the glass shade in place and tighten all the #6-32 set screws with the 1/16 Allen wrench to lock the glass shade in place.

SAVE THESE INSTRUCTIONS!

TECH LIGHTING®

7400 Linder Ave, Skokie, IL 60077
847.410.4400
www.techlighting.com

A Generation Brands Company